


## ClimaVision

This document describes the steps to remove a CCU from a ClimaVision site and clear the memory on the device. This process is useful when using a demo kit or equivalent to do training. It is advisable to do this process at the end of a training session so the CCU is ready to go for the next training session.


### 1. STEP 1: Unregister the CCU

- 1.1. Ensure the CCU is connected to Wi-Fi.
- 1.2. Click the gear icon in the top-right corner and then the gear icon in the quick access menu on the left to get to account settings.
- 1.3. Click the UNREGISTER button at the bottom-right.




### 2. STEP 2: Clear the ClimaVision app data


- 2.1. Swipe down from the upper right corner of the CCU and click the gear. On the original CCU, swipe down twice to see the gear icon. Note, screenshots below are from the original CCU and will look slightly different than the CCU XR.





### 2.2. Scroll down to Apps




### 2.3. Select ClimaVision (not ClimaVision Home)



### 2.4. Select Storage and then Clear Data



### 2.5. Hit OK and then the Home button at the bottom (circle icon)



2.6. When the app restarts, click Allow to all three questions to allowing accessing items

**Reset to factory fresh is complete!**